

5. When all finished, press [↵] to exit the setting state.

PROMPT MODE

1. Long press [*] key with 3seconds to show “add caller”
2. Press [↓] key to choose “prompt mode ”
3. Press [*] to confirm, screen show “light vibration sound”
4. Choose the prompt mode you need and press [*] to confirm.
5. When all finished, press [↵] to exit the setting state.

PROMPT TIMING

1. Long press [*] key with 3 seconds to show “add caller”
2. Press [↓] key to choose “prompt timing”. It can choose from 01-99 seconds. 00 means prompt all the time without stopping until the power off.
3. Choose the time you need, and press [*] to confirm.
4. When all finished, press [↵] to exit the setting state.

REMOVE TIMING

1. Long press [*] key with 3 seconds to show “add caller”

5

2. Press [↓] key to choose “remove timing”
3. Press [*] to confirm, can choose from 00-99. 00 means cycle mode, all number will keep on the screen, until canceled by yourself. For 01-99 means, the call number will disappear automatically after specific time.
4. Choose the number you need. Press [*] key to confirm
5. When all finished, press [↵] to exit the setting state.

CYCLE TIMING

1. Long press [*] key with 3seconds to show “add caller”
2. Press [↓] key to choose “cycle timing”
3. Press [*] to confirm, can choose from 00-99. For example, if you choose 10 seconds. It means each 10 seconds number will cycle one time.
4. Choose the number you need. Press [*] key to confirm
5. When all finished, press [↵] to exit the setting state.

DATE & TIME

1. Long press [*] key with 3seconds to show “add caller”
2. Press [↓] key to choose “date & time”
3. Press [*] to confirm. You will see current time

6

(hours; minutes; seconds and DD/MM/YY). [↑↓] key can adjust number. [*] can let you choose the bit from hours to minutes to seconds and to day to month to year.

4. Choose the date & time you need and press [↵] to exit the setting state. Then you will see screen show the time you choose just now.

KEYBOARD SET

OFF ALL / ON ALL / 00-09, If you set as 05, the display screen must set as “ON ALL” or “05” so that they can receive the signal at the same time.

LANGUAGE

CN / EN


FACTORY RESET

1. Long press [*] key with 3 seconds to show “add caller”
2. Press [↓] key to choose “factory reset”
3. Press [*] to confirm, screen show confirm reset? yes/no
4. Choose “Yes” and Long Press [*] to confirm till screen show factory resetting.
5. When all finished, press [↵] to exit the setting state.

7

Wireless Calling System

User's Manual



	Setting key, confirm key, choose bit key
	Increase or decrease number; Check up and down history call
	Exit setting; cancel key (can cancel call number from screen)
	Long press this key can turn ON or turn OFF watch pager

ADD CALLER

1. Long press [*****] key with 3 seconds to show “add caller”.
2. Press [*****] key to confirm, showing “add 0001 ID” and Total: 001/500
3. Press [**↑↓**] key and [*****] key to choose number you need. [**↑↓**] key use for adjusting the number you need in setting state. Use [**↑↓**] key can choose from “0-9” and “A-Z”. [*****] key is use for selecting the bit in setting.
4. Press any key on the transmitter till you hear a “Di” sound and “done” words show on the watch screen, while number will go to next one. For example, choose “0001”, and press call key from button transmitter. When saving is successfully, the receiver will have “Di” sounds and “done” words show on the screen. Number will show 0002. You can go on press button to save next

1

number, till all number save.

5. When all finished, press [**↵**] to exit the setting state.

DELETE CALLER

1. Long press [*****] showing “add caller ”
2. Press [**↓**] key to choose “ delete caller”
3. Press [*****] to confirm, showing “ delete single” and “delete all”
4. Press [**↑↓**] to choose delete single or delete all
5. If choose “delete single”, press [*****] to confirm, screen show 0000. You can choose the number you want to delete and long press [*****] till screen show removed. It means you have been deleted this number.
6. If choose “delete all” please long press [*****] till screen show removing all and removed .it means you have been delete all number.
7. When all finished, press [**↵**] to exit the setting state.

KEY FUNCTION

Area Set: Can set different zone from 0-9 and A-Z when pair the service type
Turn on the watch, then go to menu “key function”→“Area set”→Area 0→Set 0’s key, press [*****] again to choose the service type what you need by [**↑↓**] key.

2

Then press specific key from button, the watch will show “successfully” word with Di sound. (That means this key from button was compatible with watch completed.)

Then press [**↵**], it show “Set 0’s key” and “copy 0 to all”, choose “copy to all”→Yes.

*For Example, the button have 3 keys with call, bill, cancel (Default), you print the “order” to replace of “bill” on this 3-keys button. “Order” as a new service type, you need pair this “order” to the watch, so that the watch can show “order” when someone press this key, so please follow above steps to set it.

Type Set: Can modify the Service type

Turn on the watch, then go to menu “key function”→“Type set”→Type 01 (you can choose the number from 01-40, stand for 40 kinds of different service type)

Then press [*****] key to show specific service type what you choose, you can modify it within 12 letter in max, using [**↑↓**] key and [*****] key.

All service type on the watch: from 01/40--40/40

• Call • Cancel • Drink • Bill • Checkout • Order • Water • Dessert • Waiter • Service • Beer • Wine • Kitchen • Chef • Bar • Help • Doctor • Nurse • Massage • Therapist • Reception • Cleaner • Office • Needle • Medicine • Drip • Emergent • Add-time • Clean • Maintain • Manage • Fault • Chairman • Director • Finance • Accredited • Security • Guarder •

3

Alarm • Counter

WORK MODE

(According to keys of button to choose what’s mode need.)

1. Long press [**↓**] key with 3 seconds to show “add caller ”
2. Press [**↓**] key to choose “ work mode ”
3. Press [*****] to confirm, screen show “single key” and “multi-key”
4. Choose the one you need and Press [*****] to confirm.
5. When all finished, press [**↵**] to exit the setting state.

DISPLAY MODE

1. Long press [*****] key with 3 seconds to show “add caller ”
2. Press [**↓**] key to choose “ display mode ”
3. Press [*****] to confirm, screen show “live view” “queue view”
4. Choose the one you need then press [*****] to confirm. “live view” means, when No.1 No.2 No.3 call in turn, screen is show 0003 0002 0001. Newest call number show on the top of screen. “queue view” means, when No.1 No.2 No.3 call in turn, screen is show 0001 0002 0003. The earliest call number show on the top of screen.

4